

DECAL INSTRUCTIONS:

Have the pitted area filled, sanded smooth & painted. Wash area with soap & water (new paint included) on which decal is to be placed.

FOR MYLAR DECAL: Trim to border of design where possible prior to removing white backing paper. Lightly spray the area with window cleaner (do not use window cleaner in aerosol can). Peel white backing paper from decal and place in position. Squeegee window cleaner from under decal beginning in center and working outward. If air bubbles occur, puncture with pin & smooth down.

Please note: These decals have been printed on a tough mylar film using mylar ink. A pressure sensitive adhesive has been employed on the back of the mylar to insure good adhesion to any clean, hard surface.

FOR VINYL CUT DECAL: Peel backing paper from decal. The decal will be stuck to the application paper. Align the decal using the design, not the application paper, and firmly press decal into place. Slowly remove the application paper starting at one corner.

Please note: The colors are fused into the vinyl eliminating stacking.

CAUTION: Inspect all decal pieces before applying to tractor. NO REFUNDS on mylar decals if applied to surface and/or if damaged. NO REFUNDS on vinyl cut decals. Store in a cool, dry place. Do not soak in water!